



No. C1571 / No. C1572

With rectangular nozzle / With round nozzle

How to attach the duct set

1. Refer to the right figure 1, and attach the nozzle and adapter on the duct. Insert the nozzle and adapter until it stops, turn the nozzle clockwise. Make sure the nozzle and adapter are firmly attached.

CAUTION
Twist the nozzle tight enough to avoid coming off.

2. Insert the assembled duct set into the suction inlet of the main unit for FA-430.

PARTS LIST

Part No.	Part Name	Specifications
C1571	Duct set / rectangular nozzle	Duct (1) / Adapter (1) / Rectangular nozzle (1) / Net (1)
C1572	Duct set / round nozzle	Duct (1) / Adapter (1) / Round nozzle (1) / Net (1)

(Fig.1)

Take care of the direction for the duct.

